


Transferring Guide eActivity files on the fx-9860G


1. Download the Guide eActivity files (zip format or .g1e format)
2. If you download a zip file, unzip it.
3. On your computer, start up FA-124.
 - (1) Click the button shown below.




- (2) Right-click as shown below.




- (3) Create new folder.




- (4) Input folder name and click "OK".




(5) Right-click on the created folder and then select “Import fx-9860 file”.




(6) Select “G1E File (*.g1e)” as shown below.



(7) Select the eActivity files you want, then click “Open”.



(8) The desired eActivity in the Computer pane.




(9) Connect the fx-9860G Slim to your computer with the USB cable.

With the fx-9860G in the LINK Mode, press [F4] and [F1] to select “USB” for the cable type setting. Press [F2] to put the fx-9860G into the receive mode, which is indicated by “Receiving” on the display.




(10) Click the button shown below.

This displays a dialog box telling you that a connecting is being established. Do not perform any operation while the dialog box is displayed.



(11) After the dialog box disappears, select the desired eActivity files, and drop them into the fx-9860G pane to install them.



(12) The eActivity files will appear when you double-click the calculator icon (“User1” in the above example). This completes installation.

** The downloaded eActivity files are now available on the fx-9860G.